









ROWS	CONTACTS	L1	L2
2-06		10	22.3
2-08		15	27.3
2-12		25	37.3
2-16		35	47.3




SECTION A-A





2-06



2-08



2-12



Standard Contact, All Positions

NO. OF ROWS	NO. OF POS.	L1	L2	L3	L4
		MM	MM	MM	MM
2	6	10	28.5	16	22.3
2	8	15	33.5	21	27.3
2	12	25	43.5	31	37.3
2	16	35	53.5	41	47.3

Series:POWERMOD
Part #:PM216MBALSP

Copyright (c) 2003
Anderson Power Products



Anderson Power Products®